

ARMOR PLATE - STEEL

REGULAR (R) K-033, FAST (F) K-081, EXTRA FAST (XF) K-032 BGE*-FREE, WEAR RESISTANT, TROWELABLE COATINGS

Armor Plate - Steels are two-component, steel filled epoxy systems specifically designed for repair of worn shafts, sheaves, and castings or for tool and die making applications. All Armor Plate - Steel systems may be drilled, tapped, filed or machined.

TYPICAL HANDLING CHARACTERISTICS @ 72 - 77 °F

	K-033 <u>Armor Plate - Steel (R)</u> Non-sag, trowelable paste	K-081 <u>Armor Plate - Steel (F)</u> Non-sag, trowelable paste	K-032 <u>Armor-Plate - Steel (XF)</u> Heavy paste
CONSISTENCY			
MAX. SERVICE TEMP, °F	250	250	200
WORKING TIME, min	40	15	5
CURING TIME, h	8	3-4	1
MIX RATIO, pbv	3 / 1	2 / 1	1 / 1
pbw	5 / 1	3.5 / 1	1.6 / 1
KIT: VOLUME, in. ³	20 lb: 200	16 lb: 176	Contact Copps

Approximate coverage per pound is 20 in.² at 0.5 in. thickness.

Working time: The working time of Armor Plate-Steel (the time you have to apply the material before it sets) will vary according to the air temperature, the temperature of the material itself, and the surface to which it is applied. Higher temperatures reduce working time and curing time. Lower temperatures increase working time and curing time.

Curing time: Ultimate hard cure is obtained in 2 to 12 hours depending on the system being used, the air temperature, and the temperature of the surface being coated.

TYPICAL PERFORMANCE CHARACTERISTICS

	K-033 <u>Armor Plate - Steel (R)</u>	K-081 <u>Armor Plate - Steel (F)</u>	K-032 <u>Armor Plate - Steel (XF)</u>
TENSILE STRENGTH, psi	4,000	4,700	3,800 ASTM D 638
FLEXURAL STRENGTH, psi	7,500	8,000	5,000 ASTM D 790
COMPRESSIVE STRENGTH, psi	12,000	15,000	9,000 ASTM D 695
TENSILE SHEAR STRENGTH, psi	2,000	1,400	1,200 ASTM D 1002
IMPACT STRENGTH, ft.-lb. FALLING BALL	7.9	4.4	6.5
WEAR RESISTANCE, % WEIGHT LOSS, HIGH VELOCITY SLIDING PARTICLES	0.5	0.5	3.2
HARDNESS, Shore D	90	90	85 ASTM D 2240

*BUTYL GLYCIDYL ETHER. The EPA (SARA Title III, section 312) lists BGE as "Toxic" (per ANSI Z129.1) by skin absorption and an immediate health hazard.

ARMOR PLATE - STEEL
REGULAR (R) K-033, FAST (F) K-081, EXTRA FAST (XF) K-032

APPLICATION INSTRUCTIONS

Step 1 - Surface Preparation

The surface to be coated must be free of all rust, scale, dirt, dust, grease, oil, release agents, or other contaminants. Preheat the surface to 100 °F (this will drive off any moisture). For smooth surfaces or where vibration is a concern, tack weld an open mesh screen or expanded metal approximately 1/16 to 1/8 inch above the surface. Chip off weld slag.

Step 2 - Measuring

Armor Plate - Steel kits are supplied with the resin and hardener pre-measured in the correct mixing ratio. It is best to empty the entire contents of both the resin and hardener containers on to the mixing board to insure the proper mixing ratio is maintained.

If less than a full kit is required for the job, both the resin and hardener **must be accurately** measured out. **DO NOT ATTEMPT TO "EYEBALL" THE AMOUNT NEEDED.** Use a scale to weigh out each component or use measuring cups to measure by volume. Adding more or less hardener will only degrade the physical properties.

If the kit is colder than 60 °F, preheat both the resin and hardener by placing the cans in a hot water bath. The material temperature should not exceed 90 °F as higher heat will reduce the working time of the mix. Heating of the cans with a torch or other direct flame is highly dangerous and should **NEVER BE DONE.**

Step 3 - Mixing

After the components have been measured on a clean, flat mixing board, mix thoroughly with a trowel until the mixture becomes a uniform color (about 2 minutes).

For mixing the largest kits, a mixing paddle and heavy duty, slow speed drill may be used. However, the mechanical energy put into the mix by the drill may result in a shortened working time and a lessening of the non-sag characteristics of the Armor Plate.

Remember, incomplete mixing will result in poor curing, loss of physical properties, and "soft spots".

Step 4 - Application

Apply the mixture immediately with a trowel or putty knife. Cover large holes or cracks with screen, paper or fiberglass cloth and apply Armor Plate - Steel over the patch and onto an adjacent solid area.

Pipes can be repaired by coating a cloth "bandage" with Armor Plate - Steel and wrapping the bandage around the pipe. An additional layer of Armor Plate - Steel should be applied over the bandage,

Step 5 - Curing Procedures

Armor Plate - Steel (R) - Cure at least 8 hours at 77 °F before returning the equipment to service.

Armor Plate - Steel (F) - Cure at least 4 hours at 77 °F before returning the equipment to service.

Armor Plate - Steel (XF) - Cure at least 2 hours at 77 °F before returning the equipment to service.

Curing procedures may be shortened by applying heat with a hot air blower or heat lamps. **DO NOT EXCEED 120 °F.**

SAFETY PRECAUTIONS

Avoid breathing of vapors. Forced local exhaust is recommended to effectively minimize exposure. NIOSH approved, organic vapor respirators and forced exhaust are recommended in confined areas, or when conditions (such as heated polymers, sanding) may cause high vapor concentrations. **DO NOT WELD ON, BURN OR TORCH ON OR NEAR, ANY EPOXY MATERIAL. HAZARDOUS VAPOR IS RELEASED WHEN AN EPOXY IS BURNED.**

WARRANTY AND DISCLAIMER

Copps Industries, Inc. gives no warranty, express or implied, and all products are sold upon condition that purchasers will make their own tests to determine the quality and suitability of the product. Copps Industries, Inc. shall be in no way responsible for the proper use and service of the product. The information given in this publication is considered to be accurate and reliable and is provided as a service only. Physical properties shown are typical. Actual properties are dependent on curing conditions and degree of cure. Any information or suggestions given are without warranty of any kind and purchasers are solely responsible for any loss arising from the use of such information or suggestions. No information or suggestions given by us shall be deemed to be a recommendation to use any product in conflict with any existing patent rights.

TB#4033 (03/12/09)