

FLOOR PATCH

K-002

GENERAL PRODUCT INFORMATION

PRODUCT: K-002 Floor Patch is an economical, 100 % solids, three component, trowelable system used for repairing concrete floors.

DESCRIPTION: K-002 Floor Patch adheres to concrete, asphalt, wood, aluminum, steel and most other construction materials.

USES: K-002 Floor Patch can be used on new or old concrete. Proper surface preparation is essential to the quality and success of the application. The concrete surface must be clean, free of oil and moisture; a rough surface will greatly enhance adhesion of K-002 Floor Patch. Pre-coating with Copps K-040 Primer will allow for easier application and improved performance.

TYPICAL CHARACTERISTICS/HANDLING PROPERTIES

COMPONENTS	Resin/Hardener/Aggregate	
COLOR	Light Grey	
MIXING RATIOS, By Weight	5 parts resin to 1 part hardener	
By Volume	4 parts resin to 1 part hardener	
AGGREGATE RATIO, By Weight	6 parts aggregate to 1 part liquid	
By Volume	4 parts aggregate to 1 part liquid	
APPLICATION THICKNESS, in.	1/8-1/2	
COVERAGE @ 1/8" thick, ft ² /lb	0.88	
WORKING TIME, min @ 77 °F	45-60	
TACK-FREE TIME, h	4-6	
CURING TIME, h	16-24	
COMPRESSIVE STRENGTH, psi	7,000	ASTM D-695
SHORE HARDNESS, Scale D	75	ASTM D-2240

PACKAGING/YIELD

K-002-10: 0.7 gal = 160 in.³

K-002-40: 2.8 gal = 635 in.³

SURFACE PREPARATION

The surface must be free of rust, scale, dirt, dust, grease, oil and release agents. For molding or casting purposes, coat the mold surface with a release agent. If appearance is not a factor, coat the surface with a suitable wax or grease. If appearance is important, you should use a commercially available release agent.

MIXING AND APPLICATION

Empty all of the hardener into the resin. Mix with a paddle or a heavy-duty low speed drill until uniform, usually 2-5 minutes. Incomplete mixing results in poor curing and soft spots. Do not use partial kits. If you need less than a complete kit, do not attempt to "eyeball" the mixture. Accurately weigh or measure the resin and hardener following the mixing ratios under HANDLING PROPERTIES. If kits are colder than 60 °F, preheat them in hot tap water - to a maximum of 90 °F. Higher temperatures will reduce the work life. Do not use a torch to heat kits.

Curing time may be shortened by applying heat with a hot air blower or heat lamps. Do not exceed 120 °F.

SAFETY

Avoid breathing of vapors. Forced local exhaust is recommended to effectively minimize exposure. NIOSH approved, organic vapor respirators and forced exhaust are recommended in confined areas, or when conditions (such as heated polymers, sanding) may cause high vapor concentrations. Do not weld on, burn or torch the backing or any epoxy material. Hazardous vapor is released when an epoxy is burned.

Wear protective clothing and rubber gloves. Avoid skin or eye contact. Wash skin with soap and water if contact occurs. If eye contact occurs, flush with water for 15 minutes and obtain medical attention.

Read and understand all cautions on can labels and material safety data sheets before using this material.

WARRANTY AND DISCLAIMER

Copps Industries, Inc. gives no warranty, express or implied, and all products are sold upon condition that purchasers will make their own tests to determine the quality and suitability of the product. Copps Industries, Inc. shall be in no way responsible for the proper use and service of the product. The information given in this publication is considered to be accurate and reliable and is provided as a service only. Physical properties shown are typical. Actual properties are dependent on curing conditions and degree of cure. Any information or suggestions given are without warranty of any kind and purchasers are solely responsible for any loss arising from the use of such information or suggestions. No information or suggestions given by us shall be deemed to be a recommendation to use any product in conflict with any existing patent rights.

TB#4002 (07/24/08)