

Armor Plate Aluminum Xtra Temp Paste– K-019

Description:	Armor Plate-Aluminum is a two-component, aluminum filled, epoxy system.		
Ordering Information:	Contact Copps		
Product Advantages:	Armor Plate-Aluminum is engineered for ease of use in diverse maintenance applications including repairs of pitted aluminum propeller blades and filling voids in aluminum castings as a non-sag trowelable paste.		
Application Guidelines:	MAXIMUM SERVICE Temp 400°F WORKING TIME 90 minutes FUNCTIONAL CURE 16 Hours MIX RATIO 5/1 by Volume (5/1 by weight)		
Physical Properties:			<u>Tests Conducted</u>
	TENSILE STRENGTH	7,000 psi	ASTM D 638
	COMPRESSIVE STRENGTH	18,000 psi	ASTM D 695
	HARDNESS, Shore D	90	ASTM D 2240
	TENSILE SHEAR STRENGTH	3500 psi	ASTM D 1002
Surface Preparation:	<p>The surface to be coated must be free of all rust, scale, dirt, dust, grease, oil, release agents or other contaminants. Preheat the surface to 100 °F to drive off any moisture.</p> <p>For smooth surfaces or where vibration is a concern, tack weld an open mesh screen or expanded metal approximately 1/16 to 1/8 inch above the surface. Chip off weld slag.</p>		
Mixing:	<p>Armor Plate products are supplied in pre-measured, ready-to-use kits. Simply empty all the hardener into the resin and mix with a mixing stick until uniform in color (usually 1 to 2 minutes). If less than a full kit is required, measure out resin and hardener onto a mixing board or flat surface. Mix together with a trowel until uniform in color (usually 1 to 2 minutes).</p> <p>Incomplete mixing will result in poor cure and soft spots.</p> <p>If the kit becomes colder than 60 °F, preheat the cans in hot tap water to a maximum of 90 °F. Excessive heat will reduce the working time. The heating of the cans with a torch is NOT recommended.</p>		

Application:

Apply the mixture immediately with a trowel or putty knife. Cover large holes or cracks with screen, paper or fiberglass cloth and apply Armor Plate over the patch and onto an adjacent sound area.

**Curing
Procedures:**

For service up to 300 °F - Allow at least 8 hours cure @ 72 °F; then preheat for at least 3 hours at peak operating temperature.

For service above 300 °F - Allow 8 hours cure @ 72 °F; then preheat 3-4 hours @ 350 °F or operating temperature. DO NOT EXCEED 450 °F.

Curing procedures may be shortened by applying heat with a heat gun or heat lamps. **DO NOT EXCEED 120 °F BEFORE THE PRODUCT HARDENS.**

SAFETY PRECAUTIONS

Avoid breathing of vapors. Forced local exhaust is recommended to effectively minimize exposure. NIOSH approved, organic vapor respirators and forced exhaust are recommended in confined areas, or when conditions (such as heated polymers, sanding) may cause high vapor concentrations. **DO NOT WELD ON, BURN OR TORCH ON OR NEAR, ANY EPOXY MATERIAL. HAZARDOUS VAPOR IS RELEASED WHEN AN EPOXY IS BURNED.**

Avoid skin or eye contact. Wash skin with soap and water if contact occurs. If eye contact occurs flush with water for 15 minutes and obtain medical attention. Read and understand all cautions on can labels and safety data sheets before using this material.

WARRANTY AND DISCLAIMER

Copps Industries, Inc. gives no warranty, express or implied, and all products are sold upon condition that purchasers will make their own tests to determine the quality and suitability of the product. Copps Industries, Inc. shall be in no way responsible for the proper use and service of the product. The information given in this publication is considered to be accurate and reliable and is provided as a service only. Physical properties shown are typical. Actual properties are dependent on curing conditions and degree of cure. Any information or suggestions given are without warranty of any kind and purchasers are solely responsible for any loss arising from the use of such information or suggestions. No information or suggestions given by us shall be deemed to be a recommendation to use any product in conflict with any existing patent rights.