

10600 N. Industrial Drive Mequon, WI 53092-4473 262-238-1700 (Tel.) 262-238-1701 (Fax) www.coppsindustries.com

**Technical Bulletin** 

## Armor Plate Wear Compound-High-Temp-K-037

| Description:               | Armor Plate Wear Compounds are two component ceramic bead filled epoxy systems specifically designed to resist abrasive wear and corrosion in severe service conditions.  |  |   |
|----------------------------|---|--|---|
| Ordering<br>Information:   | K-037-11.5 (11.5 LB Unit)<br>K-037-25 (25 LB Unit)<br>K-037-45 (45 LB Unit)   |  |   |
| Intended Use:              | Repair and protect processing equipment such as pump casings, slurry lines, pipe elbows, chutes, cyclones, fans, coal breakers, pulverizers, and other high wear areas.   |  |   |
| Product<br>Advantages:     | Outstanding slide and impact resistance<br>Resistant to a wide range of chemicals<br>Non-Sagging when applied to vertical and   | overhead areas   |   |
| Application<br>Guidelines: | MAXIMUM SERVICE TEMP 450°F (232°C)<br>WORKING TIME 90 minutes<br>FUNCTIONAL CURE - See Curing Procedur<br>MIX RATIO 4/1 by Volume (4/1 by weight  | res  |   |
| Coverage:                  | Coverage per pound is 26.5in <sup>2</sup> (171cm <sup>2</sup> ) at 0.5in (1.27cm) thickness. The working time of Armor Plate Wear Compound (the time you have to apply the material before it sets) will vary according to the air temperature, the temperature of the material itself, and the surface to which it is applied.   |  |   |
| Physical<br>Properties:    | TENSILE STRENGTH<br>FLEXURAL STRENGTH<br>COMPRESSIVE STRENGTH<br>TENSILE SHEAR STRENGTH<br>WEAR RESISTANCE (weight loss) %<br>HARDNESS, Shore D   | 3,700 psi<br>8,600 psi<br>16,000 psi<br>2,200 psi<br>0.6<br>90 | Tests Conducted<br>ASTM D 638<br>ASTM D 790<br>ASTM D 695<br>ASTM D 1002<br>ASTM D 2240 |
| Surface<br>Preparation:    | The surface area must be free of all rust, scale, dirt, dust, grease, oil, or other contaminants. Thoroughly clean surface with a solvent to remove all contaminants. Grit blast surface area to be coated for optimal performance. If grit blast is not possible, grind with a coarse grinding wheel to white metal. For smoother surfaces or where vibration is a concern, tack weld an open mesh screen or expanded metal approximately 1/16 to 1/8 inch above the surface. Chip off welding slag. |  |   |
| Measuring:                 | Armor Plate ceramic kits are supplied with the resin and hardener pre-measured in the correct mixing ratio. It is best to empty the entire contents of the resin and hardener containers on a mixing board to ensure the proper mixing ratio is maintained.   |  |   |
|                            | If less than a full kit is required for the job,<br>out. <b>DO NOT ATTEMPT TO "EYEBALL" THE</b><br>component. Adding more or less hardener  | AMOUNT NEEDED. Use a scale to                                  | weigh out each  |

| Mixing:               | After the components have been measured on a clean, flat mixing board, mix thoroughly with a trowel until a uniform color is achieved. For mixing the larger kits a mixing paddle and heavy duty drill may be used. However the mechanical energy put into the mix by the drill may result in a shorter working time and a reduction of the non-sag characteristics of Armor Plate. Remember that incomplete mixing will result in poor curing, loss of physical properties, and "soft spots". |
|-----------------------|--|
| Application:          | Initially apply a thin, wet coat to the surface to create tack. Build upon the tack coat to the desired thickness. If a screen or expanded metal is used for reinforcement, apply an excess of material at one end of the area and push it through the screen. Push the material so that it "wets" the surface below the screen and moves it in a continuous mass toward the other end of the area.  |
| Curing<br>Procedures: | For service up to 300°F (148.9 °C): Allow at least 8 hours cure at 77 °F (25 °C) or higher. Then preheat for<br>at least 3 hours at the peak operating temperature prior to start up.<br>For Service above 300 °F: Allow 8 hours cure at 77 °F (25 °C) or higher. Preheat 3 to 4 hours at 400 °F<br>(204.4 °C) or peak operating temperature. DO NOT EXCEED 450 °F (232°C).  |

## **SAFETY PRECAUTIONS**

Avoid breathing of vapors. Forced local exhaust is recommended to effectively minimize exposure. NIOSH approved, organic vapor respirators and forced exhaust are recommended in confined areas, or when conditions (such as heated polymers, sanding) may cause high vapor concentrations. **DO NOT WELD ON, BURN OR TORCH ON OR NEAR, ANY EPOXY MATERIAL. HAZARDOUS VAPOR IS RELEASED WHEN AN EPOXY IS BURNED.** 

Avoid skin or eye contact. Wash skin with soap and water if contact occurs. If eye contact occurs flush with water for 15 minutes and obtain medical attention. Read and understand all cautions on can labels and safety data sheets before using this material.

## WARRANTY AND DISCLAIMER

Copps Industries, Inc. gives no warranty, express or implied, and all products are sold upon condition that purchasers will make their own tests to determine the quality and suitability of the product. Copps Industries, Inc. shall be in no way responsible for the proper use and service of the product. The information given in this publication is considered to be accurate and reliable and is provided as a service only. Physical properties shown are typical. Actual properties are dependent on curing conditions and degree of cure. Any information or suggestions given are without warranty of any kind and purchasers are solely responsible for any loss arising from the use of such information or suggestions. No information or suggestions given by us shall be deemed to be a recommendation to use any product in conflict with any existing patent rights.