

Crete Patch – K-070

Description:	K-070 Crete Patch is a versatile three component, 100 % solids epoxy with a stiff, non-sag consistency that trowels easily on vertical or overhead surfaces. K-070 patches a wide variety of materials.		
	K-070 Crete Patch adheres tightly to concrete construction materials. It bonds tightly to wet s impact - reducing chipping and spalling - and will compressive strength – 7,000 psi - means K-070 textured surface that is slip and abrasion resistant	surfaces, working even underwater not shrink, crack, or become brittle Crete Patch withstands heavy load	the second secon
	K-070 is used to patch or repair cracked, spalled or paste, K-070 may be applied to vertical, horizonta to make wet or dry repairs to pipes, pumps, valve will repair worn concrete or blacktop.	I, or curved surfaces. K-070 Crete F	Patch may be used
	Little surface preparation is needed when using K repaired area is ready for service overnight. Solv surface.		
Handling Properties:	COMPONENTS COLOR MIXING RATIOS, Resin/Hardener, pbw (pbv) Resin+Hardener/Aggregate, pbw (pbv) APPLICATION THICKNESS, in. WORKING TIME, h TACK-FREE TIME, h CURING TIME, h COVERAGE @ 1/8 in. thick, ft ² /lb	Resin/Hardener/Aggregate Light Grey 1/1.4 (1/1.3) 1/1 (1.4/1) 1/8-1 or greater 1 4-6 16-24 0.91	
Physical Properties:	COMPRESSIVE STRENGTH, psi HARDNESS, Shore D	7,000 60	ASTM D 695 ASTM D 2240
Surface Preparation:	The surface must be free of rust, scale, dirt, dust, purposes, coat the mold surface with a release age with a suitable wax or grease. If appearance is im release agent.	ent. If appearance is not a factor, co	at the surface

Mixing:	Do not use partial kits. If kits are colder than 60 °F, preheat them in hot tap water to a maximum of 90 °F. Higher temperatures will reduce the working time. Do not use a torch to heat kits. Empty all of the hardener into the resin.
	Mix with a paddle and a heavy-duty low speed drill until uniform, usually 2-5 minutes. Incomplete mixing results in poor curing and soft spots. Slowly add the aggregate and mix until uniform.
	If you need less than a complete kit, do not attempt to "eyeball" the mixture. Accurately weigh or measure the resin and hardener following the mixing ratios under HANDLING PROPERTIES.
	Cure time may be shortened by applying heat with a heat gun or heat lamps. Do not exceed 120 °F.
	K-070 Crete Patch, before it has hardened, can be removed from tools with Copps Enviro Kleen solvent.
Packaging:	K-070-35: 2.5 gal = 578 in. ³

SAFETY PRECAUTIONS

Avoid breathing of vapors. Forced local exhaust is recommended to effectively minimize exposure. NIOSH approved, organic vapor respirators and forced exhaust are recommended in confined areas, or when conditions (such as heated polymers, sanding) may cause high vapor concentrations. **DO NOT WELD ON, BURN OR TORCH ON OR NEAR ANY EPOXY MATERIAL. HAZARDOUS VAPOR IS RELEASED WHEN AN EPOXY IS BURNED.** Read and understand all cautions on can labels and safety data sheets before using this material.

WARRANTY AND DISCLAIMER

Copps Industries, Inc. gives no warranty, express or implied, and all products are sold upon condition that purchasers will make their own tests to determine the quality and suitability of the product. Copps Industries, Inc. shall be in no way responsible for the proper use and service of the product. The information given in this publication is considered to be accurate and reliable and is provided as a service only. Physical properties shown are typical. Actual properties are dependent on curing conditions and degree of cure. Any information or suggestions given are without warranty of any kind and purchasers are solely responsible for any loss arising from the use of such information or suggestions. No information or suggestions given by us shall be deemed to be a recommendation to use any product in conflict with any existing patent rights.