

10600 N. Industrial Drive Mequon, WI 53092-4473 262-238-1700 (Tel.) 262-238-1701 (Fax) www.coppsindustries.com

**Technical Bulletin** 

## Flexfill 90 Joint Filler – K-560

Description:	Flexfill 90 has been specifically designed for filling sawcut control joints and contraction joints in concrete. Flexfill 90 is a two component, low viscosity liquid which cures to a semi-rigid, hard-rubber-like resiliency which supports joint edges to prevent edge deterioration and concrete spalling. Flexfill 90 joint filler bonds tightly to the sides of concrete joints, prevents contaminant and water penetration, and delivers high wear resistance and durability.					
Product Advantages:	<ul> <li>VOC FREE, 100% SOLIDS</li> <li>FAST 3 HOUR SHAVE TIME</li> <li>IDEAL 1:1 MIX RATIO</li> <li>HIGH RESILIENCY</li> <li>BONDS TO MOST CONSTRUCTION MATERIALS</li> <li>EASILY COATED WITH COMPATIBLE TOPPINGS</li> <li>THIXOTROPIC JOINT FILLER CONSISTENCY- DESIGNED TO REDUCE JOINT FILLER "SINKERS" SAVING TIME AND MONEY</li> </ul>					
Handling Properties:	MIX RATIO BY VO COLOR: WORKLIFE, AFTE APPLICATION TH SHAVE TIME: CURING TIME: MIXED VISCOSIT	R MIXING RESIN & HARDENER: ICKNESS:	8-10 1/8" 3 hoi 16 ho	1:1 light grey 8-10 min.@ 72°F 1/8" or greater 3 hours@ 72°F 16 hours@ 72°F 8,000 cPs ASTM D 2196		
Physical Properties:	TENSILE STRENGTH: %TENSILE ELONGATION: HARDNESS (SHORE A):		540 g 40% 92A	6		
	WHAT TYPE OF JOINT ARE YOU FILLING?					
		TYPE 1		TYPE 2		
		FLEXFILL 90 HERE		<u>T</u> USE FLEXFIL		
	Names*: Characteristics:	Control joint Contraction joint Non-working joint No movement or negligible movement Sawcut	Names*: Characteristics:	Expansion joi Isolation join Working join Significant n Significant n Formed	nt nt novement Formed	
	*Name distinctions are based on American Concrete Institute, ACI 504R-90					
Joint Preparation:	sound joint. In add intended filler dep (if possible vacuur run against each s vacuumed to rem	ny loose concrete, previous joint compound or other materials must be removed to leave a clean, bund joint. In addition, all dirt, oil, sealers or chemical residue must also be removed for the full itended filler depth. To achieve optimum performance the joint must be sawcut with a diamond blade f possible vacuum-equipped) in order to achieve a clean/dry surface for bonding. The blade should be in against each sidewall and extended the entire intended filler depth. After sawing, joint should be accumed to remove all dust/debris ("raking" debris out of joint is an unacceptable joint cleaning rocedure). To prevent filler run-through you may "choke-off" the bottom of the joint by applying a ¼"				

procedure). To prevent filler run-through you may "choke-off' the bottom of the joint by applying a ¼" deep (maximum) layer of dry, silica sand (30-60 mesh). Do not use a backer rod in saw cut contraction /control joints less than 2" deep. For those joints greater than 2" and construction joints (through-slab) you may use silica sand or a backer rod only if it is held down at least 2" from the top of joint.

Flooring • Grouts • Wear Resistant Coatings • Adhesives • Custom Formulating • Epoxy Varnishes • Potting Compounds

Mixing:	Mix the Resin (Part A) and the Hardener (Part B) for 2-3 minutes with a slow speed (500 rpm or less) drill and Jiffy Mixer (mixing paddle). Pour the material into the joint. If a flush joint is desired slightly overfill the joint and let cure, then use a floor scraper or knife-edge to cut the material flush with the concrete. If you need less than a full kit, do not "eyeball" the mixture. Accurately measure the resin and hardener following the mixing ratios under "Handling Properties". Flexfill 90 has a work life of 8-10 minutes at 72 °F (22 °C), and can be applied as thickly as needed in one coat. If it is necessary to bond Flexfill 90 to itself, abrade the old material before pouring new material.				
	Flexfill 90, before it has fully cured, may be removed from tools with Copps Enviro Kieen solvent or isopropyl alcohol.				
Application:	Flexfill 90 should not be installed on "green" concrete. A minimum 30-day concrete cure is required. 90-120 days is ideal. The ideal time to install is when the area is at its long term, stable temperature. Do not rapidly change the temperature of the air/concrete before installing Flexfill 90. Keep the temperature constant, same as long term temperature. Floor temperature must be between 60-90 °F (15.5- 32.2°C) during application for complete cure. Temperatures below 50 °F (10 °C) will inhibit the cure resulting in a sticky surface. The liquid material should be stored at 60-90 °F prior to installation.				
Additional Info:	<ul> <li>Important product characteristics include tensile strength, percentage tensile elongation and Shore A hardness.</li> <li>These characteristics relate to Flexfill 90 after it has completely cured.</li> </ul>				
	In simple terms:     Torgile strength relates to the sense its of this metanicities hold to get here there there is a sense its of this metanicities hold to get here there is a sense its of this metanicity of this metanicity of the sense is a sense its of the sense is a				
	Tensile strength relates to the capacity of this material to hold together when stretched.				
	Percentage tensile elongation is the length the material can be stretched before failure.				
	Shore A hardness relates to a standard for "hardness -softness" so that different materials may be measured against the same reference point.				
	Flexfill 90 has been designed to function as a joint filler. It must stretch or give to allow for expansion or contraction within the concrete slab. At the same time it must deliver adequate support to joint shoulders receiving the force of hard wheel traffic carrying heavy loads. It must bond to joint sides to provide a seal to prevent contaminant entry and its surface texture must deliver sufficient wear capacity. Extensive tests and use of Flexfill 90 demonstrate these capacities.				
Packaging:	K-56020 (2 gallon) Premeasured Kit = 439 in <sup>3</sup> K-560-100 (10 gallon) Premeasured Kit= 2217 in <sup>3</sup> Bulk 55 Gallon Drums Available				

## **SAFETY PRECAUTIONS**

Flexfill 90 is an epoxy resin system. Please refer to safety data sheets before using this product. DO NOT WELD ON, BURN OR TORCH ON OR NEAR ANY EPOXY MATERIAL.

## WARRANTY AND DISCLAIMER

Copps Industries, Inc. gives no warranty, express or implied, and all products are sold upon condition that purchasers will make their own tests to determine the quality and suitability of the product. Copps Industries, Inc. shall be in no way responsible for the proper use and service of the product. The information given in this publication is considered to be accurate and reliable and is provided as a service only. Physical properties shown are typical. Actual properties are dependent on curing conditions and degree of cure. Any information or suggestions given are without warranty of any kind and purchasers are solely responsible for any loss arising from the use of such information or suggestions. No information or suggestions given by us shall be deemed to be a recommendation to use any product in conflict with any existing patent rights.